





















































Original	Substituto	Original	Substituto
 Power	 Power	 Main Page	 Smart
 Menu	 Menu	 Play	 Play
 Title	 List	 Pause	 Pause
 Setup	 Options	 Stop	 Stop
 Angle	 Red	 <<	 <<
 Repeat	 Text	 >>	 >>
 A-B Repeat	 TV/R	 I<<	 I<<
 Slow	 Pre Ch	 >>I	 >>I
 File Info	 Info	 Video	 Yellow
 Time Search	 AV	 Audio	 Dual
 Brt. Cont.	 Green	 Subtitle	 Subt
 Media Type	 Media	 Scr Size	 Format
 Up	 Up	 Vol+	 Vol +
 Down	 Down	 Vol-	 Vol -
 Right	 Right	 Mute	 Mute
 Left	 Left	 1	 1
 Enter	 Ok	 2	 2

Original	Substituto	Original	Substituto
 MUTE	 MUTE	 Smart	 Smart
 DVD	 SAT	 Play	 Play
 PAUSE	 PAUSE	 Stop	 Stop
 <<	 <<	 >>	 >>
 DUAL	 SUBT	 I<<	 I<<
 TV/R	 FORMAT	 >>I	 >>I
 REPEAT	 3D	 Video	 Yellow
 D.MENU	 AV	 Audio	 Dual
 MENU	 INFO	 Subtitle	 Subt
 OK	 BACK	 Scr Size	 Format
 EXIT	 SMART	 Vol+	 Vol +
 VOL	 MEDIA	 Vol-	 Vol -
 -	 CH	 Mute	 Mute
 1	 2	 1	 1
 2	 3	 2	 2
 3	 4	 MUTE	 MUTE
 4	 5	 1	 1
 5	 6	 2	 2
 6	 7	 GUIDE	 FAV
 7	 8	 0	 PRE-CH
 8	 9	 A	 B
 9	 0	 C	 D
 0	 CANCEL	 Mandis SHOP	 Mandis SHOP
 +	 SMART	 www.mandis.tv	 www.mandis.tv
 -	 MEDIA		



