






























































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	-/--		Guide
	TV TX		Text
	OK		Ok
	Up / CH+		Up
	Up / CH+		Ch +
	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	[≡]		Info
	Mix		Shift + Text
	Brightness		Shift + 1
	Contrast		Shift + 2
	Color		Shift + 3
	Menu		Menu
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue





Original	Substituto	Original	Substituto
 Stop	 Stop		
 Reveal	 Play		
 Update	 Pause		
 Clock	 Options		
 Sub	 Subt		
 Double	 Dual		
 Stereo A B	 I<<		
 Stereo Sol	 <<		
 Stereo Fa	 >>		
 Stereo	 >>		
 Stereo PS	 List		

