
















































| Original | Substituto | Original | Substituto |
|-------------|---|------------|---|
| On/Off |  Power | OK Enter |  OK |
| Mute |  Mute / Dimmer | Menu Right |  Right |
| Txt Stop |  Stop / Hold | Menu Off |  Exit / Cancel / Clear |
| Reveal |  Pause / Step / Freeze | Menu Down |  Down |
| Update |  Play / Slow | Back |  Back / Return |
| Info |  Info / Angle | Volume+ |  Vol+ |
| Subt.List |  Subtitle / EQ | Chan.Up |  CH+ / Page+ |
| Sleep Timer |  Sleep / Timer | Volume- |  Vol- |
| Return TV |  TV/Radio / | Menu audio |  Audio / Lang I/II |
| Menu video |  D.Menu / Top | Chan.Down |  CH- / Page- |
| Text |  Text / Goto | 1 |  1 |
| Txt Expand |  Zoom / Size | 2 |  2 |
| TV/AV |  AV / Input / RDS | 3 |  3 |
| Menu |  Menu / Home | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Display / Media | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Substituto | Original | Substituto |
|---------------|---|-----------------|---|
| 8 |  8 | Color- S.Std |  Sound / Title |
| 9 |  9 | Contrast+ |  >> / Preset+ |
| Guide -/-- 1. |  Guide / EPG / -/-- | Contrast- |  << / Preset- |
| 0/10 |  0 | Surround |  Eject / Surround |
| 2.Fav P/C 2. |  Fav / Marker / PC | Nicam/Mono |  Shift + Audio / Lang I/II |
| Red |  Red / Netflix / Search | AV 2 |  Shift + AV / Input / RDS |
| Green |  Green / APP / Repeat | Bright+ Mode |  Shift + CH+ / |
| Yellow |  Yellow / YouTube / Repeat | Level L |  Shift + Left |
| Blue |  Blue / Prime Video / Random | Level R/Woofers |  Shift + Right |
| Color+ P.Std |  Picture / Format | Disp |  Shift + Display / Media |
| Off/Tim |  Setup / OPT / | Bright- Sys |  Shift + CH- / |
| Tune- |  << / Tune- | | |
| Audio- |  Shift + Vol- | | |
| Mix Scan |  Smart / List | | |
| Audio+ |  Shift + Vol+ | | |
| Game Coo |  Rec / Rec Mode | | |
| Tune+ |  >> / Tune+ | | |

