








































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV/AV		AV
	STD / [≡X]		Smart
	M		Media
	i		Text
	OO		D. Menu
	Format		TV/R
	⊖ Sleep		<<
	3D		<<





Original	Substituto	Original	Substituto
	[≡>1]		>>
	[≡0]		Options

