

| Original | Substituto | Original | Substituto |
|-------------|---|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Update |  Play | Menu Off |  Exit |
| Reveal |  Pause | Menu Down |  Down |
| Txt Stop |  Stop | Back |  Back |
| Info |  Rec | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Menu audio |  Dual |
| Menu video |  D. Menu | Chan.Down |  Ch - |
| Text |  Text | 1 |  1 |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Substituto | Original | Substituto |
|----------------|---|----------------|------------|
| 8 |  | 8 | |
| 9 |  | 9 | |
| Guide -/-- 1. |  | Guide | |
| 0/10 |  | 0 | |
| 2.Fav P/C 2. |  | Pre Ch | |
| Red |  | Red | |
| Green |  | Green | |
| Yellow |  | Yellow | |
| Blue |  | Blue | |
| Audio+ |  +  | Shift + Pause | |
| Tone- |  | << | |
| Tone+ |  | >> | |
| On/Tim |  +  | Shift + Subt | |
| Game Coo |  +  | Shift + Eject | |
| Disp |  +  | Shift + Info | |
| Browse |  +  | Shift + Back | |
| 3.* |  +  | Shift + Guide | |
| Surround |  +  | Shift + Red | |
| Nicam/Mono |  +  | Shift + Green | |
| Level L |  +  | Shift + Yellow | |
| Level R/Woofer |  +  | Shift + Blue | |



| Original | Substituto | Original | Substituto |
|-------------|---|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Update |  Play | Menu Off |  Exit |
| Reveal |  Pause | Menu Down |  Down |
| Txt Stop |  Stop | Back |  Back |
| Info |  Rec | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Menu audio |  Dual |
| Menu video |  D. Menu | Chan.Down |  Ch - |
| Text |  Text | 1 |  1 |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Substituto | Original | Substituto |
|---------------|--|--------------|--|
| 8 |  8 | Color+ P.Std |  +  Shift + Format |
| 9 |  9 | Game Coo |  +  Shift + Eject |
| Guide -/-- 1. |  GUIDE | Bright+ Mode |  +  Shift + Menu |
| 0/10 |  0 | Search |  +  Shift + Up |
| 2.Fav P/C 2. |  PRE-CH | Disp |  +  Shift + Info |
| Red |  A | Tune- |  +  Shift + Left |
| Green |  B | Tune+ |  +  Shift + Right |
| Yellow |  C | Store |  +  Shift + Down |
| Blue |  D | Browse |  +  Shift + Back |
| Rotate Text |  +  Shift + Mute | Contrast+ |  >>I |
| Audio+ |  +  Shift + Pause | Color- S.Std |  +  Shift + Dual |
| Tone- |  << | Contrast- |  I<< |
| Tone+ |  >> | 3.* |  +  Shift + Guide |
| On/Tim |  SMART | 4.# 16:9 |  Format |
| Off/Tim |  MEDIA | Surround |  +  Shift + Red |
| Mix Scan |  +  Shift + TV/R | Nicam/Mono |  +  Shift + Green |
| Store Text |  +  Shift + Text | Level L |  +  Shift + Yellow |



