







Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	EPG		Guide
	[...]		Subt
	i		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	Exit		Exit

Original	Substituto	Original	Substituto
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol+		Right
	Vol-		Vol -
	Vol-		Left
	OK/Store		Ok
	P+		Up
	P-		Down
	RCL		Options
	Red/Tv/Radio		Red
	Green/FAV		Green
	Yellow/Audio?		Yellow
	Blue/SAT		Blue
	White		Back

