




Original	Substituto	Original	Substituto
 Standby	 Power	 2	 2
 Mute	 Mute	 3	 3
 Up	 Up	 4	 4
 Left	 Left	 5	 5
 OK	 Ok	 6	 6
 Right	 Right	 7	 7
 Down	 Down	 8	 8
 Menu	 Menu	 9	 9
 Exit	 Exit	 0	 0
 Red / UHF	 Red	 EPG	 Guide
 Green / Audio	 Green	 Group	 Pre Ch
 Green / Audio	 Dual	 Vol+	 Vol +
 Yellow / Pause	 Yellow	 Vol-	 Vol -
 Yellow / Pause	 Pause	 CH+	 Ch +
 Blue / Recall	 Blue	 CH-	 Ch -
 Blue / Recall	 Back	 Page+	 >>
 1	 1	 Page-	  <<

 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 Group	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Page+	 >>
 Page-	  <<



