

































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	PP		Back / Return
	I - II		Audio / Lang I/II
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Fav / Marker / PC
	--		Guide / EPG / --
	M/Menu		Menu / Home

Original	Substituto	Original	Substituto
	i		Info / Angle
	PR+		CH+ / Page+
	PR-		CH- / Page-
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol+
	Vol-		Vol-
	Red/Sound		Red / Netflix / Search
	Green/Picture		Green / APP / Repeat
	Yellow/Feature		Yellow / YouTube / Repeat
	Blue/Install		Blue / Prime Video / Random
	TV		TV/Radio /
	AV		AV / Input / RDS
	[=]		Text / Goto
	[=o]		Subtitle / EQ



