








































| Original | Substituto | Original | Substituto |
|---|------------|--|----------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | -/-- |  | Shift + Guide / EPG / -/-- |
|  | 0 |  | 0 |
|  | Recall |  | Back / Return |
|  | P.Mode |  | Picture / Format |
|  | S.Mode |  | Sound / Title |
|  | FAV |  | Fav / Marker / PC |

| Original | Substituto | Original | Substituto |
|---|------------|---|------------------------|
|  | Vol+ |  | Vol+ |
|  | MTS /II |  | Audio / Lang I/II |
|  | CH+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | Sub-T |  | Subtitle / EQ |
|  | CH- |  | CH- / Page- |
|  | Aspect |  | Zoom / Size |
|  | Freeze |  | Shift + Pause / Step / |
|  | Sleep |  | Sleep / Timer |
|  | Source |  | AV / Input / RDS |
|  | Up |  | Up |
|  | Display |  | Display / Media |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Menu |  | Menu / Home |
|  | Down |  | Down |





| Original | Substituto | Original | Substituto |
|----------|--------------|---------------------|-----------------------------|
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| Red | Red | NETFLX SEARCH | Red / Netflix / Search |
| Green | Green | APP REPEAT | Green / APP / Repeat |
| Yellow | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| Blue | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| TEXT/CC | << / Text/CC | TUNE- | << / Tune- |
| TEXT/CC | << / Text/CC | GOTO TEXT | Text / Goto |
| SUB.PG | Play/Pause / | STEP-FREEZE | Pause / Step / Freeze |
| SUB.PG | Play/Pause / | SLOW | Play / Slow |
| REVEAL | >> / Reveal | TUNE+ | >> / Tune+ |
| HOLD | I<< / Hold | PRESET- | I<< / Preset- |
| SIZE | >>I / Size | PRESET+ | >>I / Preset+ |
| INDEX | Stop / Index | HOLD | Stop / Hold |
| ROOT | Root | OPT-TOOLS SETUP | Setup / OPT / |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| LIST | List | LIST SMART | Smart / List |
| T.SHIFT | T.Shift | TOP MENU D.MENU | D.Menu / Top |

| Original | Substituto |
|-----------|-------------------|
| REC | Rec |
| EPG | EPG |
| REC MODE | Rec / Rec Mode |
| GUIDE EPG | Guide / EPG / -/- |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

