






















































































Original	Substituto	Original	Substituto
 Power	 Power	 Vol+	 Vol+
 Mute	 Mute / Dimmer	 Vol-	 Vol-
 1	 1	 Page+	 Shift + CH+ /
 2	 2	 Page-	 Shift + CH- /
 3	 3	 CH+	 CH+ / Page+
 4	 4	 CH-	 CH- / Page-
 5	 5	 Lang	 Audio / Lang I/II
 6	 6	 Timeshift	 Smart / List
 7	 7	 Tv/Radio	 TV/Radio /
 8	 8	 EPG	 Guide / EPG / -/-
 9	 9	 Up	 Up
 List	 Shift + Smart / List	 Down	 Down
 Recall	 Back / Return	 Left	 Left
 FAV	 Fav / Marker / PC	 Right	 Right
 Subtitle	 Subtitle / EQ	 OK	 OK
 Info	 Info / Angle	 Menu	 Menu / Home
 TTX	 Text / Goto	 Exit	 Exit / Cancel / Clear





Original	Substituto	Original	Substituto
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 >>	 >>  / Preset+		
 Rec	 Rec / Rec Mode		
 <<	 << / Tune-		
 >>	 >> / Tune+		
  <<	  << / Preset-		
 Stop	 Stop / Hold		
 Timer	 Sleep / Timer		
 PVR	 AV / Input / RDS		
 V-Format	 Shift + 4		
 Aspect	 Picture / Format		

Original	Substituto

