



Original	Substituto	Original	Substituto
	Power		Power
	Sleep		Sleep / Timer
	GE Effect		Smart / List
	GE M.Call		Back / Return
	<< Tape A		<< / Tune-
	>> Tape A		>> / Tune+
	<< Tape B		Shift + << /
	>> Tape B		Shift + >> /
	< Tape A		Shift + Pause / Step /
	> Tape A		Shift + Play /
	< Tape B		Left
	> Tape B		Right
	Stop Tape A		Shift + Stop /
	Rec Tape B		Rec / Rec Mode
	Pause Tape B		Pause / Step / Freeze
	Stop Tape B		OK
	I<< CD		I<< / Preset-
	>>I CD		>>I / Preset+
	Tuner Band		6
	Play/Pause CD		Play / Slow
	Stop CD		Stop / Hold
	P.Scan Up		CH+ / Page+
	Mute		Mute / Dimmer
	< Phono		Guide / EPG / -/-
	Stop Phono		0
	P.Scan Down		CH- / Page-
	Volume Control +		Vol+
	Video		4
	Dat		2
	AUX		7
	Volume Control -		Vol-

