





























































































Original	Substituto	Original	Substituto
	Subtitle		Subtitle / EQ
	Format		Picture / Format
	Red / Timer		Sleep / Timer
	Up / CH+		Up
	Down / CH-		Down
	Red / Timer		Red / Netflix / Search
	Right / Vol+		Right
	Left / Vol-		Left
	Page Up		CH+ / Page+
	Right / Vol+		Vol+
	Left / Vol-		Vol-
	OK		OK
	Back		Back / Return
	TV/R		TV/Radio /
	Info		Info / Angle
	EPG		Guide / EPG / -/-
	Fav		Fav / Marker / PC
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Page down		CH- / Page-
	Blue		Blue / Prime Video / Random
	Prev		I<< / Preset-
	Next		>>I / Preset+
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	FRW		<< / Tune-
	Play		Play / Slow
	FFW		>> / Tune+
	7		7
	Mute		Mute / Dimmer
	Menu		Menu / Home
	Exit		Exit / Cancel / Clear
	1		1





Original	Substituto	Original	Substituto
	2		2
	3		3
	4		4
	5		5
	6		6
	Power		Power
	8		8
	9		9
	0		0
	List		Smart / List
	Lang		Audio / Lang I/II
	TXT		Text / Goto

