


























































































Original	Substituto	Original	Substituto
 Power	 Power	 (≡?)	 Play / Slow
 Mute	 Mute / Dimmer	 Freeze	 Pause / Step / Freeze
 1	 1	 Aspect	 Shift + Picture / Format
 2	 2	 Audio	 Audio / Lang I/II
 3	 3	 Sleep	 Sleep / Timer
 4	 4	 Picture	 Picture / Format
 5	 5	 Source	 AV / Input / RDS
 6	 6	 (≡x)	 Rec / Rec Mode
 7	 7	 Hold	 Stop / Hold
 8	 8	 P+	 CH+ / Page+
 9	 9	 Up	 Up
 i	 Info / Angle	 Left	 Left
 0	 0	 Vol-	 Vol-
 R	 Back / Return	 Menu	 Menu / Home
 (≡i)	 >> / Tune+	 Right	 Right
 (◆)	 I<< / Preset-	 Vol+	 Vol+
 (≡o)	 << / Tune-	 P-	 CH- / Page-





Original	Substituto
 Down	 Down
 (≡)(-)	 Text / Goto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 PIP Source	 Shift + 3
 PIP Main	 Shift + 2
 PIP Swap	 Shift + 5
 PIP Position	 Shift + 4
 PIP Size	 Shift + 6
 PIP	 Shift + 1

Original	Substituto

