

























































































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	USB/Media 1		Display / Media
	USB/Media 1		Shift + 8
	Play/Pause/Text		Text / Goto
	Play/Pause/Text		Play / Slow
	Play/Pause/Text		Pause / Step / Freeze
	Stop/Index		Stop / Hold
	Rec/Media2		Rec / Rec Mode
	Rec/Media2		Shift + Display / Media
	I<</Hold		I<< / Preset-
	>>I/Size		>>I / Preset+
	<</S.Page		<< / Tune-
	>>/Reveal		>> / Tune+
	I-II/Nicam		Shift + Picture / Format
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Tv/Radio		TV/Radio /
	i		Info / Angle
	Sleep		Sleep / Timer
	Source		AV / Input / RDS
	Menu		Menu / Home
	Left		Left
	Up		Up
	Right		Right
	OK		OK
	Down		Down
	Mouse		Shift + OK
	Smart		Smart / List
	Exit		Exit / Cancel / Clear
	CH+		CH+ / Page+
	EPG		Guide / EPG / -/-
	VOL+		Vol+
	CH-		CH- / Page-





Original	Substituto	Original	Substituto
 Open/Close	 Eject / Surround	 9	 9
 Vol-	 Vol-	 FAV	 Fav / Marker / PC
 D.Setup	 Setup / OPT /	 0	 0
 Picture	 Picture / Format	 Recall	 Back / Return
 D.Menu	 D.Menu / Top	 Red	 Red / Netflix / Search
 Sound	 Sound / Title	 Green	 Green / APP / Repeat
 D.Title	 Shift + Sound / Title	 Yellow	 Yellow / YouTube / Repeat
 P.Size	 Zoom / Size	 Blue	 Blue / Prime Video / Random
 D.Prog	 Shift + TV/Radio / Program		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		

Original	Substituto	Original	Substituto
 9	 9	 9	 9
 FAV	 Fav / Marker / PC	 0	 0
 Recall	 Back / Return	 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat	 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random		

