













































































Original	Substituto	Original	Substituto
 Mult	 Smart / List	 Right	 Right
 Search	 Red / Netflix / Search	 ADD	 Fav / Marker / PC
 1	 1	 Down	 Down
 2	 2	 FN	 Info / Angle
 3	 3	 I<	 I<< / Preset-
 4	 4	 I>	 Pause / Step / Freeze
 5	 5	 </I	 CH- / Page-
 6	 6	 >>	 >> / Tune+
 7	 7	 >I	 >>I / Preset+
 8	 8	 Rec	 Rec / Rec Mode
 9	 9	 >/I	 CH+ / Page+
 Esc	 Exit / Cancel / Clear		
 0	 0		
 -/--	 Guide / EPG / -/--		
 Up	 Up		
 Left	 Left		
 Menu	 Menu / Home		

Original	Substituto	Original	Substituto
 Right	 Right	 ADD	 Fav / Marker / PC
 Down	 Down	 I<	 I<< / Preset-
 I>	 Pause / Step / Freeze	 </I	 CH- / Page-
 >>	 >> / Tune+	 >I	 >>I / Preset+
 Rec	 Rec / Rec Mode	 >/I	 CH+ / Page+

