



Original	Substituto	Original	Substituto
 Green/Timer	 Green / APP / Repeat	 Down/P-	 Down
 Power	 Power	 P-	 CH- / Page-
 Yellow	 Yellow / YouTube / Repeat	 Menu	 Menu / Home
 Red/Audio	 Red / Netflix / Search	 OK	 OK
 Blue	 Blue / Prime Video / Random	 Help/?	 Smart / List
 Colour-	 << / Tune-	 1	 1
 Colour+	 >> / Tune+	 2	 2
 Brightness-	 I<< / Preset-	 3	 3
 Brightness+	 >>I / Preset+	 4	 4
 TV	 TV/Radio /	 5	 5
 Display	 Display / Media	 6	 6
 Up/P+	 Up	 7	 7
 P+	 CH+ / Page+	 8	 8
 Left/V-	 Left	 9	 9
 V-	 Vol-	 Top 10	 Fav / Marker / PC
 Right/V+	 Right	 0/AV	 0
 V+	 Vol+	 Mute	 Mute / Dimmer

