



| Original | Substituto | Original | Substituto        |
|----------|------------|----------|-------------------|
|          | Power      |          | Power             |
|          | Source     |          | AV / Input / RDS  |
|          | 1          |          | 1                 |
|          | 2          |          | 2                 |
|          | 3          |          | 3                 |
|          | 4          |          | 4                 |
|          | 5          |          | 5                 |
|          | 6          |          | 6                 |
|          | 7          |          | 7                 |
|          | 8          |          | 8                 |
|          | 9          |          | 9                 |
|          | TTX/MIX    |          | Text / Goto       |
|          | 0          |          | 0                 |
|          | PRE-CH     |          | Fav / Marker / PC |
|          | Vol+       |          | Vol+              |
|          | Mute       |          | Mute / Dimmer     |
|          | CH+        |          | CH+ / Page+       |

| Original | Substituto  | Original | Substituto              |
|----------|-------------|----------|-------------------------|
|          | Vol-        |          | Vol-                    |
|          | CH List     |          | Smart / List            |
|          | CH-         |          | CH- / Page-             |
|          | Netflix     |          | Shift + Red / Netflix / |
|          | Home        |          | Menu / Home             |
|          | prime video |          | Shift + Blue / Prime    |
|          | Samsung TV  |          | TV/Radio /              |
|          | Up          |          | Up                      |
|          | Disney+     |          | Picture / Format        |
|          | Left        |          | Left                    |
|          | Enter       |          | OK                      |
|          | Right       |          | Right                   |
|          | Return      |          | Back / Return           |
|          | Down        |          | Down                    |
|          | Exit        |          | Exit / Cancel / Clear   |
|          | Red         |          | Red / Netflix / Search  |
|          | Green       |          | Green / APP / Repeat    |



