



































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	TV/RAD		TV/Radio /
	www		Sleep / Timer
	PIP		Zoom / Size
	Grid		D.Menu / Top
	Swap		Back / Return
	Sub ch		Setup / OPT /
	P/Pg+		CH+ / Page+
	RCL		Display / Media
	Vol+		Vol+
	P/Pg-		CH- / Page-
	i		Info / Angle
	Vol-		Vol-
	FAV		Fav / Marker / PC
	Check		Smart / List
	Message		Eject / Surround
	EPG		Guide / EPG / -/-
	Up		Up
	Menu		Menu / Home
	Left		Left
	OK		OK
	right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Substituto	Original	Substituto
 6	 6	 TXT	 Text / Goto
 7	 7	 Audio	 Audio / Lang I/II
 8	 8		
 9	 9		
 Music	 Sound / Title		
 0	 0		
 Photo	 Picture / Format		
 Rec	 Rec / Rec Mode		
 <<	 << / Tune-		
 Play	 Play / Slow		
 >>	 >> / Tune+		
 Recall	 AV / Input / RDS		
   >	 >>  / Preset+		
 Stop/→	 Stop / Hold		
 Pause	 Pause / Step / Freeze		
 [ ]]	 Shift + Zoom /		
 [...]	 Subtitle / EQ		

