



Original	Substituto
 Power	 Power
 Open / Close	 Eject / Surround
 Language	 Audio / Lang I/II
 Angle	 Info / Angle
 Subtitle	 Subtitle / EQ
 Time	 Sleep / Timer
 Display	 Display / Media
 PDVD	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Substituto
 0/10	 0
 10+	 Guide / EPG / -/-
 Prog	 TV/Radio /
 Mute	 Mute / Dimmer
 Zoom	 Zoom / Size
 A-B	 Yellow / YouTube / Repeat
 Repeat	 Green / APP / Repeat
 Step	 Shift + Pause / Step /
 Slow	 Shift + Play /
 Return	 Back / Return
 Resume	 Fav / Marker / PC
 View	 AV / Input / RDS
 Ran	 Blue / Prime Video / Random
 Vol-	 Vol-
 Vol+	 Vol+
 Menu	 Menu / Home
 Up	 Up



