



Original	Substituto	Original	Substituto
	Power		Power
	Input		AV / Input / RDS
	Disney+		Shift + 1
	YouTube		Shift + Yellow / YouTube /
	prime video		Shift + Blue / Prime
	Rakuten Tv		Shift + 4
	Plex		Shift + 5
	deezer		Shift + 6
	f Watch		Shift + 7
	Kid		Shift + 8
	NBA League		Shift + 9
	Netflix		Shift + Red / Netflix /
	VIDAA tv		Shift + 2
	VIDAA free		Shift + 3
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat

Original	Substituto	Original	Substituto
	Blue		Blue / Prime Video / Random
	[=]		D.Menu / Top
	Up		Up
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Exit		Exit / Cancel / Clear
	Vol+		Vol+
	Home		Menu / Home
	CH+		CH+ / Page+
	Vol-		Vol-
	Mute		Mute / Dimmer
	CH-		CH- / Page-





Original		Substituto	
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Info		Info / Angle
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Guide		Guide / EPG / -/--
	0		0
	CH.List		Smart / List

