



Original	Substituto
 Power	 Power
 Display	 Shift + Info
 Mute	 Mute
 Video	 Back
 Scart	 Smart
 PC	 Media
 TV	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Substituto
 Subpage	 Eject
 PRE-CH	 Pre Ch
 Source	 AV
 PIP	 3D
 Sound	 Dual
 Sleep	 Sleep
 DTV Menu	 D. Menu
 Zoom-	 <<
 Zoom+	 >>
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down





Original	Substituto	Original	Substituto
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Teletext		Text
	Mix		Options
	Info		Info
	Index		Guide
	Size		Format
	Hold		List
	Subtitle		Subt
	Reveal	+	Shift + Text

