



Original	Substituto	Original	Substituto
 Index	 Play / Slow	 6	 6
 Red / -1	 Red / Netflix / Search	 Contrast-	 << / Tune-
 Green / Timer /	 Green / APP / Repeat	 Contrast+	 >> / Tune+
 Yellow / Stop	 Yellow / YouTube / Repeat	 7	 7
 Blue / Reveal	 Blue / Prime Video / Random	 8	 8
 [≡]]	 Rec / Rec Mode	 9	 9
 Cancel	 Exit / Cancel / Clear	 Brightness-	 I<< / Preset-
 Size	 Zoom / Size	 Brightness+	 >>I / Preset+
 TV	 TV/Radio /	 P/C	 Back / Return
 Text	 Text / Goto	 0	 0
 1	 1	 AV	 AV / Input / RDS
 2	 2	 Display / Media	 Display / Media
 3	 3	 Smart / List	 Smart / List
 Tint-	 Shift + Left	 PIP	 Picture / Format
 Tint+	 Shift + Right	 i	 Info / Angle
 4	 4	 i	 Menu / Home
 5	 5	 ----	 Subtitle / EQ


























Original	Substituto	Original	Substituto
 Up / P+	 Up		
 Up / P+	 CH+ / Page+		
 Mute	 Mute / Dimmer		
 Left / Vol-	 Left		
 Left / Vol-	 Vol-		
 OK	 OK		
 Right / Vol+	 Right		
 Right / Vol+	 Vol+		
 AUX	 Shift +  7		
 Down / P-	 Down		
 Down / P-	 CH- / Page-		
 Power	 Power		





Original	Substituto	Original	Substituto
	<		I<< / Preset-
	>		>>I / Preset+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	P+		CH+ / Page+
	P-		CH- / Page-
	Power		Power





Original	Substituto	Original	Substituto
-1	Red / Netflix / Search	*+	>>  / Preset+
+1	Green / APP / Repeat	P/C	Back / Return
STOP	Yellow / YouTube / Repeat	0	0
E7	Blue / Prime Video / Random	PIP	Picture / Format
E8	Text / Goto	i	Info / Angle
1	1	P+	CH+ / Page+
2	2	Up	Up
3	3	Mute	Mute / Dimmer
4	4	Left	Left
5	5	Vol-	Vol-
6	6	OK	OK
-0	<< / Tune-	Right	Right
0+	>> / Tune+	Vol+	Vol+
7	7	AUX	Shift + 7
8	8	P-	CH- / Page-
9	9	Down	Down
-*	<< / Preset-	Power	Power

