




































| Original | Substituto |
|--|---|
|  Power |  Power |
|  Favorite Program |  Pre Ch |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Tv/VCR |  TV/R |
|  AD-Skip |  Guide |
|  Rec/OTR |  Rec |
|  Eject |  Eject |
|  Play |  Play |

| Original | Substituto |
|---|---|
|  >>/F.FWD |  >> |
|  <</REW |  << |
|  Pause/Still |  Pause |
|  Stop |  Stop |
|  Channel/Tracking |  Ch + |
|  Channel/Tracking- |  Ch - |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK/CLK/CNT |  Ok |
|  Clear |  Exit |
|  i/Menu |  Menu |
|  Speed |  Smart |
|  AV |  AV |
|  Rec End Search |  3D |
|  Child Lock |  Media |



