



























































Original	Substituto	Original	Substituto
 Power	 Power	 TV	 TV/R
 1	 1	 AV	 TV/R
 2	 2	 Up / P+	 Up
 3	 3	 Up / P+	 Ch +
 4	 4	 Down / P-	 Down
 5	 5	 Down / P-	 Ch -
 6	 6	 Right / V+	 Right
 7	 7	 Right / V+	 Vol +
 8	 8	 Left / V-	 Left
 9	 9	 Left / V-	 Vol -
 0	 0	 Menu	 Menu
 Mute	 Mute	 Menu	 Ok
 16:9	 Format	 S / M / D	 Smart
 Red	 Red	 Recall	 Pre Ch
 Green	 Green	 Recall	 Back
 Yellow	 Yellow	 ≡	 Text
 Blue	 Blue	 /≡	 Options

Original	Substituto	Original	Substituto
 TV	 TV/R	 TV	 TV/R
 AV	 AV	 Up / P+	 Up
 Up / P+	 Ch +	 Up / P+	 Ch +
 Down / P-	 Down	 Down / P-	 Down
 Down / P-	 Ch -	 Right / V+	 Right
 Right / V+	 Vol +	 Right / V+	 Vol +
 Left / V-	 Left	 Left / V-	 Left
 Left / V-	 Vol -	 Menu	 Menu
 Menu	 Ok	 Menu	 Ok
 S / M / D	 Smart	 S / M / D	 Smart
 Recall	 Pre Ch	 Recall	 Pre Ch
 Recall	 Back	 Recall	 Back
 ≡	 Text	 ≡	 Text
 /≡	 Options	 /≡	 Options



