















































| Original | Substituto |
|---|--|
|  Standby |  Power |
|  Auto / Eject |  Eject / Surround |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Tv / Radio |  TV/Radio / |
|  Recall |  Back / Return |
|  Vol+ |  Vol+ |
|  Title / Pr List |  Shift + Sound / Title |
|  Title / Pr List |  Smart / List |

| Original | Substituto |
|--|---|
|  Menu / EPG |  D.Menu / Top |
|  Menu / EPG |  Guide / EPG / -/- |
|  Ch+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  FAV |  Fav / Marker / PC |
|  Ch- |  CH- / Page- |
|  Up |  Up |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  LCD Menu / Exit |  Menu / Home |
|  Down |  Down |
|  DVD Setup / Exit |  Setup / OPT / |
|  DVD Setup / Exit |  Shift + Exit / Cancel / Clear |
|  Input |  AV / Input / RDS |
|  P.Mode |  Picture / Format |
|  S.Mode |  Sound / Title |





| Original | Substituto |
|--|--|
|  Mute |  Mute / Dimmer |
|  Play / Pause |  Play / Slow |
|  Play / Pause |  Pause / Step / Freeze |
|  Exit / Stop |  Exit / Cancel / Clear |
|  Exit / Stop |  Stop / Hold |
|  Sleep |  Sleep / Timer |
|  Audio |  Audio / Lang I/II |
|  << |  << / Tune- |
|  >> |  >> / Tune+ |
|  Zoom |  Zoom / Size |
|  Subpage / Goto |  Text / Goto |
|  Index / I<< |  I<< / Preset- |
|  Size / >>I |  Shift + Zoom / Zoom / |
|  Size / >>I |  >>I / Preset+ |
|  Reveal |  Display / Media |
|  Subtitle |  Subtitle / EQ |
|  Red / Mode |  Red / Netflix / Search |

| Original | Substituto |
|---|---|
|  Green / Clear |  Green / APP / Repeat |
|  Yellow / Repeat |  Yellow / YouTube / Repeat |
|  Yellow / Repeat |  Shift + Green / APP / |
|  Blue / AB |  Blue / Prime Video / Random |
|  Blue / AB |  Shift + Yellow / YouTube / |

