







































































Original	Substituto	Original	Substituto
	Power		Power
	Menu		Menu
	Q.Menu		D. Menu
	Exit		Exit
	Back		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	PR +		Ch +
	PR-		Ch -
	i		Info
	Guide/Tv+Book		Shift + Options
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	TV		TV/R
	[≡]/Text		Text





Original	Substituto	Original	Substituto
 */o..	 Eject		
 Source/Game	 AV		
 */o	 List		
 World	 Guide		
 Music/Movie/Phot	 Options		
 [-O-]	 Sleep		
 [≡]..	 Subt		
 Lang	 Dual		
 Rec	 Rec		
 Stop	 Stop		
 Pause	 Pause		
 Play	 Play		
 >>	 >>		
 <<	 <<		

