














































Original	Substituto	Original	Substituto
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Zoom	 Eject
 0	 0	 P+	 Ch +
 AV	 AV	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 Green	 Green
 Exit	 Exit	 Yellow	 Yellow
 FAV	 Pre Ch	 Blue	 Blue

Original	Substituto	Original	Substituto
 EPG	 Guide	 EPG	 Guide
 Up	 Up	 Up	 Up
 Down	 Down	 Down	 Down
 Right	 Right	 Right	 Right
 Left	 Left	 Left	 Left
 OK	 Ok	 OK	 Ok
 Vol+	 Vol +	 V+	 Vol +
 Vol-	 Vol -	 V-	 Vol -
 Info	 Info	 INFO	 Info
 Audio	 Dual	 AUDIO	 Dual
 Zoom	 Eject	 ZOOM	 Eject
 P+	 Ch +	 P+	 Ch +
 P-	 Ch -	 P-	 Ch -
 Red	 Red	 SAT	 Red
 Green	 Green	 TEXT	 Green
 Yellow	 Yellow	 SUB	 Yellow
 Blue	 Blue	 RCL	 Blue





Original		Substituto	
	SAT		Smart
	Text		Text
	Sub		Subt
	RCL		Options
	Pause		Pause
	<I		I<<
	I>		>>I
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Stop		Stop

Original		Substituto	

