










































































































Original	Substituto	Original	Substituto
 Power	 Power	 Text	 Text
 1	 1	 CH+	 Ch +
 2	 2	 CH+	 Up
 3	 3	 CH-	 Ch -
 4	 4	 CH-	 Down
 5	 5	 Vol+	 Vol +
 6	 6	 Vol+	 Right
 7	 7	 Vol-	 Vol -
 8	 8	 Vol-	 Left
 9	 9	 Menu	 Menu
 0	 0	 Menu	 Ok
 Red	 Red	 S.Mode	 Shift + Dual
 Green	 Green	 Mute	 Mute
 Yellow	 Yellow	 Still	 Pause
 Blue	 Blue	 Zoom	 Eject
 Display	 Info	 Lang	 Dual
 P.Mode	 Format	 Video	 Shift + 1

Original	Substituto	Original	Substituto
 MUTE		 TV	 DVD
 TV	 SAT	 AUX	
 PLAY MODE		 Play	 Pause
 STOP		 Fast Backward	 Fast Forward
 DISC NAV	 SOUND	 AD	
 LIST	 DUAL	 SUBT	
 PROG	 SEARCH	 PICTURE	
 SLEEP	 TV/R	 FORMAT	
 E-MANUAL	 REPEAT	 ZOOM	
 D.MENU	 TEXT		
 TOP MENU		 MENU	
		 CLEAR	
 EXIT		 VOL+	 HOME
		 VOL-	 APP
			
		 1	 2
		 4	 5
		 5	 6
		 6	 8
		 7	 9
		 8	
		GUIDE	 0
		A	 B
		C	