











Original	Substituto	Original	Substituto
 Mute	 Mute	 Left	 Left
 Power	 Power	 Enter	 Ok
 Subtitle	 Subt	 Stop	 Stop
 Language	 Dual	 L / R	 3D
 Open / Close	 Eject	 1	 1
 Angle	 Format	 2	 2
 Prog	 Sleep	 Goto	 Media
 Title	 List	 3	 3
 Menu	 Menu	 4	 4
 Vol +	 Vol +	 5	 5
 Vol -	 Vol -	 6	 6
 Setup	 Options	 7	 7
 Play / Pause	 Play	 8	 8
 Play / Pause	 Pause	 9	 9
 Up	 Up	 10+	 Guide
 Down	 Down	 0	 0
 Right	 Right	 << Rev	 <<

Original	Substituto	Original	Substituto
 Left	 Left	 Enter	 Ok
 Stop	 Stop	 L / R	 3D
 1	 1	 2	 2
 Goto	 Media	 3	 3
 4	 4	 5	 5
 6	 6	 7	 7
 8	 8	 9	 9
 10+	 Guide	 0	 0
 << Rev	 <<		





Original		Substituto	
	>> Fwd		>>
	I<< Prev		I<<
	>>I Next		>>I
	Display		Info
	Slow	+	Shift + Play
	Step	+	Shift + Pause
	PBC		Smart
	Zoom	+	Shift + Eject
	Repeat		Text
	A - B	+	Shift + Text
	Video / Mode		TV/R

Original	Substituto

