












	Original	Substituto		Original	Substituto
	 Power	 Power		 Exit	 Exit
	 Mute	 Mute		 Up	 Up
	 1	 1		 Down	 Down
	 2	 2		 Right	 Right
	 3	 3		 Left	 Left
	 4	 4		 OK	 Ok
	 5	 5		 Vol+	 Vol +
	 6	 6		 Vol-	 Vol -
	 7	 7		 Sound	 Shift + Dual
	 8	 8		 PIC	 Options
	 9	 9		 CH+	 Ch +
	 0	 0		 CH-	 Ch -
	 Audio	 Dual		 Sleep	 Sleep
	 Recall	 Back		 Aspect	 3D
	 Tv-Menu	 Menu		 Freeze	 Shift + Media
	 Source	 AV		 Tv/Radio	 TV/R
	 CH.List	 List		 Text	 Text





	Original	Substituto		Original	Substituto
	EPG	 Guide		<<	  <<
	FAV	 Pre Ch		>>	 >>
	Info	 Info		Play	 Play
	Red	 Red		Pause	 Pause
	Green	 Green		Stop	 Stop
	Yellow	 Yellow		Rec/Rep	 Rec
	Blue	 Blue			
	Reveal	 Eject			
	Hold	 D. Menu			
	List	 Smart			
	Index	 Shift + Info			
	Subpage	 Shift + Subt			
	Size	 Format			
	MIX	 Media			
	Subtitle	 Subt			
	<<	 <<			
	>>	 >>			

