
















































































Original	Substituto	Original	Substituto
 Power	 Power	 Up	 Up
 Eject	 Eject	 CH+	 Ch +
 1	 1	 CH-	 Ch -
 2	 2	 Down	 Down
 3	 3	 Left	 Left
 4	 4	 Right	 Right
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 Mute	 Mute
 8	 8	 EPG/P/N	 Guide
 9	 9	 Exit/Slow	 Exit
 0	 0	 Tv/Radio	 TV/R
 Menu/PgDn	 Menu	 TTX	 Text
 Title/PgUp	 Info	 Audio	 Dual
 Setup	 Options	 Subtitle	 Subt
 Return	 Back	 Play	 Play
 Enter	 Ok	 Pause	 Pause





Original	Substituto
 Stop	 Stop
 DVD/DVB	 Media
 USB	 AV
 Video	 Smart
 Search	 Shift + TV/R
 Info/Display	 Shift + Info
 Random	 3D
 Repeat	 Shift + Text
 Q-Play	 Shift + Media
 Zoom	 Shift + Eject
 Angle	 Shift + 3D
 List/PBC	 List
 Red	 Red
 I<<	 I<<
 >>I	 >>I
 Green	 Green
 Yellow	 Yellow

Original	Substituto
 <<	 <<
 Blue	 Blue
 >>	 >>
 FAV/A-B	 Pre Ch

