
































































Original	Substituto	Original	Substituto
 Power	 Power	 9	 9
 Red	 Red / Netflix / Search	 0/AV	 0
 Green	 Green / APP / Repeat	 P+	 CH+ / Page+
 Yellow	 Yellow / YouTube / Repeat	 P-	 CH- / Page-
 Blue	 Blue / Prime Video / Random	 Vol+	 Vol+
 [=+]	 Setup / OPT /	 Vol-	 Vol-
 [ / = ]	 AV / Input / RDS	 N/E	 OK
 [=x]	 Picture / Format	 Right	 Right
 [=]	 Text / Goto	 Left	 Left
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 P/C	 Back / Return
 4	 4	 i	 Info / Angle
 5	 5	 Mute	 Mute / Dimmer
 6	 6	 Color-	 << / Tune-
 7	 7	 Color+	 >> / Tune+
 8	 8	 Brightness-	 I<< / Preset-





Original	Substituto	Original	Substituto
 Brightness+	 >>I / Preset+		
 Tint-	 Display / Media		
 Tint+	 Smart / List		





Original	Substituto	Original	Substituto
	Power		Power
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	0/AV		0
	Vol+		Vol+
	Vol-		Vol-
	P+		CH+ / Page+
	P-		CH- / Page-
	Down		Down
	Up		Up
	N/E		OK
	Right		Right
	Left		Left
	i		Info / Angle
	Mute		Mute / Dimmer
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Tint-		Display / Media
	Tint+		Smart / List
	<<		<< / Tune-
	>>		>> / Tune+
	I>		Zoom / Size
	I<<		I<< / Preset-
	>>I		>>I / Preset+

