






























Original	Substituto	Original	Substituto
	Standby		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Mem		Rec / Rec Mode
	<< Scan		<< / Tune-
	Scan >>		>> / Tune+
	I<< Preset		I<< / Preset-
	Preset >>I		>>I / Preset+
	Open/Close		Eject / Surround
	Auto (Tuner)		TV/Radio /
	Input		AV / Input / RDS
	Info		Info / Angle
	Vol+		Vol+
	Vol-		Vol-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	REP/--		Green / APP / Repeat
	Speakers A/B		Yellow / YouTube / Repeat
	Dimmer		Shift + Mute / Dimmer
	<< Scan		Shift + << /
	Scan >>		Shift + >> /
	I<< Preset		Shift + I<< / Preset-
	>>I Preset		Shift + >>I / Preset+
	FM/AM (Tuner)		Shift + 6





Original	Substituto
 Open/Close	 Eject / Surround
 Input	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Dimmer	 Shift + Mute / Dimmer
 REP/--	 Green / APP / Repeat
 Play	 Play / Slow
 Pause/Auto	 Pause / Step / Freeze
 Stop/FM/AM	 Stop / Hold

Original	Substituto
 Mem	 Rec / Rec Mode
 << Scan	 << / Tune-
 Scan >>	 >> / Tune+
 Mute	 Mute / Dimmer
 I<< Preset	 I<< / Preset-
 Preset >>I	 >>I / Preset+
 Vol+	 Vol+
 Vol-	 Vol-
 Standby	 Power
 Info	 Info / Angle
 Speakers A/B	 Yellow / YouTube / Repeat

