



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Text		Text
	Back / S. Page		Back
	index / PVR List		Smart
	reveal / REC		Rec
	zoom / T.Shift		Eject
	hold / EPG		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol +		Vol +
	Vol -		Vol -
	I-II		Dual
	Source		AV
	CH +		Ch +
	CH -		Ch -
	Sleep		Sleep
	Menu		Menu
	DTV / Radio		TV/R
	Exit		Exit
	Aspect		Format
	Up		Up





Original	Substituto
	Right
	Down
	Left
	OK
	+ Shift + Format
	+ Shift + Dual
	Media
	Info
	+ Shift + Play
	Subt
	+ Shift + Stop
	+ Shift + Pause
	Play
	Pause
	I<<
	>>I
	Stop

Original	Substituto
	<<
	>>
	Pre Ch
	+ Shift + Right
	+ Shift + Left

