



| Original | Substituto | Original | Substituto |
|----------|-------------------|----------|-----------------------------|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | TV/SAT | | Smart / List |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | Radio | | TV/Radio / |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | Mute | | Mute / Dimmer |
| | 0 | | 0 |
| | Red / i | | Info / Angle |
| | Red / i | | Red / Netflix / Search |
| | Green / Audio | | Green / APP / Repeat |
| | Green / Audio | | Audio / Lang I/II |
| | Yellow / Subtitle | | Yellow / YouTube / Repeat |
| | Yellow / Subtitle | | Subtitle / EQ |
| | Menu | | Menu / Home |
| | Blue / UHF | | Blue / Prime Video / Random |
| | Up | | Up |
| | White / Timer | | Sleep / Timer |
| | White / Timer | | Fav / Marker / PC |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Exit | | Exit / Cancel / Clear |
| | Down | | Down |
| | V+ | | Vol+ |
| | P+ | | CH+ / Page+ |
| | V- | | Vol- |
| | ? | | D.Menu / Top |



