






Original	Substituto
	Mute
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	APP
	APP
	0
	Back
	L-
	L+

Original	Substituto
	Menu
	Up
	Exit
	Left
	OK
	Right
	CH+
	Down
	Vol+
	CH-
	Vol-
	Info
	List
	EPG
	Red
	Green
	Yellow





Original	Substituto
 Blue	 Blue / Prime Video / Random
 Audio	 Audio / Lang I/II
 Subt	 Subtitle / EQ
 Text	 Text / Goto
 Tv/Rad.	 TV/Radio /
 OPT	 Setup / OPT /
 Still	 Pause / Step / Freeze
 Tv/AV	 AV / Input / RDS

Original	Substituto

