



Original	Substituto	Original	Substituto
	Display		Display / Media
	Power		Power
	Normal	+	Shift + Display / Media
	Tv/Av/DVD		TV/Radio /
	Sleep		Sleep / Timer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Aspect		Smart / List
	0		0
	Sound Mode		Sound / Title
	Vol-		Vol-
	Tv Menu		Menu / Home
	Vol+		Vol+
	Up		Up
	PR+		CH+ / Page+
	Left		Left
	Right		Right
	Mute		Mute / Dimmer
	PR-		CH- / Page-
	Down		Down
	OK/Enter		OK
	DVD Menu		D.Menu / Top
	o))		AV / Input / RDS
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	[...]		Subtitle / EQ
	<<		<< / Tune-



