





























































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	[<>]		Format
	♪		Dual
	[]		3D
	PAT		Smart
	PIP Sel		Play
	PIP Pos		Pause
	PIP Size		Stop
	AV		AV
	PC		Media
	TV		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	Zoom		Eject
	Swap		Pre Ch
	Swap		Back
	PR-		Ch -
	PR+		Ch +
	Vol-		Vol -
	Vol+		Vol +
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK / Freeze		Ok





Original		Substituto	
	Info	DISPLAY	Info
	Menu	TOP MENU	Menu
	[+]	SETTINGS	Options
	[?]	E-MANUAL	D. Menu
	[◆]	AD	Subt
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text / Mix	REPEAT	Text
	[≡x]	CLEAR	Exit
	[≡:]	-/-	Guide

Original		Substituto	

