























































































Original	Substituto	Original	Substituto
	Power		Power
	Red / ↑		Red / Netflix / Search
	green / ↓		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Exit		Exit / Cancel / Clear
	[≡o]		Sleep / Timer
	[≡+]		Stop / Hold
	[≡x]		Smart / List
	[≡]		Text / Goto
	[/≡]		Setup / OPT /
	[≡♦]/[+]/Wide		Menu / Home
	[≡?]		Shift + Info / Angle
	[≡i]/Guide		Guide / EPG / -/--
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	P<P/Swap		Picture / Format
	0		0
	-/--	 + 	Shift + Guide / EPG / -/--
	Vol-		Vol-
	Vol+		Vol+
	Mute		Mute / Dimmer
	P-		CH- / Page-
	P+		CH+ / Page+
	[i]/Info		Info / Angle
	Tv/DTV		TV/Radio /
	[AV]/Source		AV / Input / RDS





Original	Substituto
	 Audio / Lang I/II
	 Back / Return
	 Up
	 Left
	 OK
	 Right
	 D.Menu / Top
	 Down

Original	Substituto

