



| Original | | Substituto | | Original | | Substituto | |
|---|--------------|---|-----------------|---|-------------|---|---------------------------|
|  | Standby |  | Power |  | CH+ |  | CH+ / Page+ |
|  | Mute |  | Mute / Dimmer |  | Vol- |  | Vol- |
|  | 1 |  | 1 |  | Zoom/Aspect |  | Shift + Zoom / |
|  | 2 |  | 2 |  | Zoom/Aspect |  | Picture / Format |
|  | 3 |  | 3 |  | CH- |  | CH- / Page- |
|  | 4 |  | 4 |  | Menu |  | Menu / Home |
|  | 5 |  | 5 |  | Up |  | Up |
|  | 6 |  | 6 |  | Exit |  | Exit / Cancel / Clear |
|  | 7 |  | 7 |  | Left |  | Left |
|  | 8 |  | 8 |  | OK/Enter |  | OK |
|  | 9 |  | 9 |  | Right |  | Right |
|  | Recall |  | Back / Return |  | Sleep |  | Sleep / Timer |
|  | 0 |  | 0 |  | Down |  | Down |
|  | List |  | Smart / List |  | Source |  | AV / Input / RDS |
|  | Vol+ |  | Vol+ |  | Red |  | Red / Netflix / Search |
|  | Info/Display |  | Display / Media |  | Green |  | Green / APP / Repeat |
|  | Info/Display |  | Info / Angle |  | Yellow |  | Yellow / YouTube / Repeat |



