






























































































Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Guide		Guide
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	>>I		>>I
	I<<		I<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/List		Ok
	Menu		Menu
	Back		Back
	Red/Text		Red
	Green/Audio		Green
	Yellow/Sub		Yellow
	Blue/Find		Blue
	<<		<<
	Play		Play
	Pause		Pause





	Original	Substituto	Original	Substituto
	>>		>>	
	Stop		Stop	
	Rec		Rec	
	PVR		Smart	
	FAV		Pre Ch	
	[+]/Ratio		3D	
	Page Up		Shift + Up	
	Page Down		Shift + Down	
	[v]/Edit		Media	
	F1/Tv/Radio		TV/R	
	F2/Input		AV	
	F3		Subt	
	F4		Options	

