








































































Original	Substituto	Original	Substituto
 Power	 Power	 Green / List	 Green
 1	 1	 Green / List	 List
 2	 2	 Yellow / <<	 Yellow
 3	 3	 Yellow / <<	 <<
 4	 4	 Blue / >>	 Blue
 5	 5	 Blue / >>	 >>
 6	 6	 Exit	 Exit
 7	 7	 Up	 Up
 8	 8	 Left	 Left
 9	 9	 OK	 Ok
 0	 0	 Right	 Right
 Mute	 Mute	 Down	 Down
 Pause	 Pause	 9PIC	 Media
 Recall	 Back	 Audio	 Dual
 Menu	 Menu	 TV / Radio	 TV/R
 Red / Sleep	 Red	 TV / VCR	 AV
 Red / Sleep	 Shift + Power	 N / P	 3D





	Original	Substituto	Original	Substituto
	FAV	 Pre Ch		
	Text	 Text		
	EPG	 Guide		
	Subtitle	 Subt		
	Info	 Info		

