































































Original	Substituto	Original	Substituto
 MUTE	Mute	 MUTE / Dimmer	Mute / Dimmer
 POWER	Power	 Power	Power
 1	1	 1	1
 2	2	 2	2
 3	3	 3	3
 4	4	 4	4
 5	5	 5	5
 6	6	 6	6
 7	7	 7	7
 8	8	 8	8
 9	9	 9	9
 --	--	 Guide / EPG / --	Guide / EPG / --
 0	0	 0	0
 PIP	PIP	 Zoom / Size	Zoom / Size
 MENU	Menu	 Menu / Home	Menu / Home
 TV/AV	TV/AV	 AV / Input / RDS	AV / Input / RDS
 Left	Left	 Left	Left
 Vol-	Vol-	 Vol-	Vol-
 Up	Up	 Up	Up
 P+	P+	 CH+ / Page+	CH+ / Page+
 Vol+	Vol+	 Vol+	Vol+
 Right	Right	 Right	Right
 P-	P-	 CH- / Page-	CH- / Page-
 Down	Down	 Down	Down
 CALL	Call	 Fav / Marker / PC	Fav / Marker / PC
 TIME	Time	 Sleep / Timer	Sleep / Timer
 FRESH	Fresh	 Subtitle / EQ	Subtitle / EQ
 VIEW	View	 Smart / List	Smart / List
 MODE	Mode	 Picture / Format	Picture / Format
 BACK	Back	 Back / Return	Back / Return

