



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	Play / Pause		Play
	USB / Stop		Stop
	USB / Stop		Media
	Sleep		Rec
	Info		Info
	Red / I<<<		Red
	Red / I<<<		I<<<
	Green / >>>I		>>>I
	Green / >>>I		Green
	Yellow / <<<		Yellow
	Yellow / <<<		<<<
	Blue / >>>		Blue
	Blue / >>>		>>>
	FAV		Pre Ch
	SAT		AV
			Up
			Left
			OK
			Right
			Down
			Menu
			Exit
			Subtitle
			TXT
			Recall
			Audio
			Page +
			Page -
			1
			2
			3
			4



