





































| Original | Substituto | Original | Substituto |
|-------------------------------------------------------------------------------------|--------------|-------------------------------------------------------------------------------------|------------|
|  | Power |  | Power |
|  | Open / Close |  | Exit |
|  | Display |  | Info |
|  | Setup |  | Options |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Guider |  | Guide |

| Original | Substituto | Original | Substituto |
|---------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------|------------|
|  | Contents |  | Smart |
|  | Source |  | AV |
|  | TV / Mode |  | TV/R |
|  | Up |  | Up |
|  | Left |  | Left |
|  | Enter |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Top Menu |  | D. Menu |
|  | Menu |  | Menu |
|  | Stop |  | Stop |
|  | Play |  | Play |
|  | > |  | Pause |
|  | I<< |  | I<< |
|  | >>I |  | >>I |
|  | << |  | << |
|  | >> |  | >> |



