




































































Original	Substituto	Original	Substituto
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Blue	 Blue
 Pause	 Pause	 CH+	 Ch +
 <<<	 <<<	 CH-	 Ch -
 >>>	 >>>	 Source	 AV
 I<<<	 I<<<	 Vol+	 Vol +
 >>I	 >>I	 Vol-	 Vol -
 Stop	 Stop	 Menu	 Menu
 TV/TXT	 Text	 Rec	 Rec
 Cancel	 Eject	 Up	 Up
 Reveal	 D. Menu	 Down	 Down
 Hold	 Media	 Right	 Right
 Size	 3D	 Left	 Left
 Subpage	 Shift + Subt	 OK	 Ok
 Index	 List	 DVB	 Smart
 Red	 Red	 Exit	 Exit
 Green	 Green	 1	 1





Original	Substituto	Original	Substituto
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/--	SHIFT + Guide
Recall	Recall	RETURN BACK	Back
PICTURE	Picture	SHIFT + PICTURE FORMAT	SHIFT + Format
SOUND	Sound	SHIFT + SOUND DUAL	SHIFT + Dual
NICAM/A2	Nicam/A2	SETTINGS OPT	Options
MUTE	Mute	MUTE	Mute
SLEEP	Sleep	PROG SLEEP	Sleep
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R

Original	Substituto	Original	Substituto
FAV	FAV	FAV PRE-CH	Pre Ch
FAV+	FAV+	SHIFT + + CH	Shift + Ch +
FAV-	FAV-	SHIFT + - CH	Shift + Ch -
SUBTITLE	Subtitle	AD SUBT	Subt
PIC FORMAT	Pic Format	PICTURE FORMAT	Format
TEXT	Text	SHIFT + REPEAT TEXT	Shift + Text
DISPLAY	Display	DISPLAY INFO	Info
LANGUAGE	Language	SOUND DUAL	Dual
EPG	EPG	-/-- GUIDE	Guide

