







































































Original	Substituto	Original	Substituto
 Power	 Power	 -/--	 Shift + Guide
 Mute	 Mute	 TV Menu	 Menu
 Source	 AV	 DVB Menu	 D. Menu
 PMode	 Format	 D.Exit	 Exit
 SMode	 Shift + Dual	 QV	 Pre Ch
 I/II	 Dual	 Call	 Back
 Sleep	 Sleep	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 V-	 Vol -
 6	 6	 V+	 Vol +
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original	Substituto
	Yellow
	Blue
	Subt
	3D
	Stop
	Smart
	Text
	Shift + Info
	Shift + Back
	Shift + Text
	Shift + Subt
	Shift + Pre Ch
	Info
	Options
	TV/R
	Guide

Original	Substituto

