
























































| Original  | Substituto | Original  | Substituto           |
|---|------------|---|----------------------|
|    | Power      |    | Power                |
|    | Aspect     |    | Picture / Format     |
|    | Mute       |    | Mute / Dimmer        |
|    | 1          |    | 1                    |
|    | 2          |    | 2                    |
|    | 3          |    | 3                    |
|    | 4          |    | 4                    |
|    | 5          |    | 5                    |
|    | 6          |    | 6                    |
|    | 7          |    | 7                    |
|   | 8          |   | 8                    |
|  | 9          |  | 9                    |
|  | List       |  | Smart / List         |
|  | 0          |  | 0                    |
|  | Repeat     |  | Green / APP / Repeat |
|  | Vol+       |  | Vol+                 |
|  | S          |  | Subtitle / EQ        |

| Original  | Substituto       | Original  | Substituto                    |
|---|------------------|---|-------------------------------|
|    | CH+              |    | CH+ / Page+                   |
|    | Vol-             |    | Vol-                          |
|    | Audio            |    | Audio / Lang I/II             |
|    | CH-              |    | CH- / Page-                   |
|    | i                |    | Info / Angle                  |
|    | Guide            |    | Guide / EPG / -/-             |
|    | Rec              |    | Rec / Rec Mode                |
|    | Menu             |    | Menu / Home                   |
|    | Up               |    | Up                            |
|    | Input            |    | AV / Input / RDS              |
|   | Left             |   | Left                          |
|  | OK               |  | OK                            |
|  | Right            |  | Right                         |
|  | Back             |  | Back / Return                 |
|  | Down             |  | Down                          |
|  | Exit / DVD Setup |  | Exit / Cancel / Clear         |
|  | Exit / DVD Setup |  | Shift + Exit / Cancel / Clear |





| Original          | Substituto                     |
|-------------------|--------------------------------|
| Red / Prog        | Red / Netflix / Search         |
| Red / Prog        | Shift + Red / Netflix / Search |
| Green / Step      | Shift + Green / APP / Repeat   |
| Yellow / Goto     | Yellow / YouTube / Repeat      |
| Blue / A-B        | Blue / Prime Video / Random    |
| Index / Stop      | Pause / Step / Freeze          |
| Hold / Play/Pause | Shift + Stop /                 |
| Hold / Play/Pause | Stop / Hold                    |
| Reveal / <<       | << / Tune-                     |
| Size / >>         | >> / Tune+                     |
| FAV / Menu        | Fav / Marker / PC              |
| FAV / Menu        | Shift + Fav / Marker / PC      |
| TV.RD / Angle     | TV/Radio /                     |
| Mix / I<<         | I<< / Preset-                  |
| S.Page / >>I      | Shift + >>I / Preset+          |
| S.Page / >>I      | >>I / Preset+                  |
| Title             | Sound / Title                  |

| Original    | Substituto               |
|-------------|--------------------------|
| Slow        | Play / Slow              |
| Text / Zoom | Shift + Text /           |
| Text / Zoom | Text / Goto              |
| Cancel /    | Shift + Eject / Surround |
| Cancel /    | Eject / Surround         |

