



















































Original	Substituto	Original	Substituto
	Input		AV / Input / RDS
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Pro. List		Smart / List
	0		0
	Last		Back / Return
	Info		Info / Angle
	Up		Up
	Menu		Menu / Home

Original	Substituto	Original	Substituto
	Left		Left
	OK		OK
	Right		Right
	EPG		Guide / EPG / -/--
	Down		Down
	Text		Text / Goto
	Vol+		Vol+
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol-		Vol-
	I/I-II		Display / Media
	P-		CH- / Page-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[≡i]/Index		Shift + AV / Input / RDS





Original	Substituto
MIX [ /≡]/Mix	SHIFT + GOTO TEXT Shift + Text /
SIZE [≡♦]/Size	SIZE ZOOM Zoom / Size
SUBTITLE [≡B]/Subtitle	EQ SUBTITLE Subtitle / EQ
HOLD [≡+]/Hold	HOLD Stop / Hold
REVEAL [≡?]/Reveal	SHIFT + ANGLE INFO Shift + Info / Angle
SOUND (·)/Sound	TITLE SOUND Sound / Title
PIC [ ]/Pict	FORMAT PICTURE Picture / Format
FAV ♥/FAV	PC FAV MARKER Fav / Marker / PC
FREEZE */Freeze	OPT-TOOLS SETUP Setup / OPT /
SLEEP Sleep	TIMER SLEEP Sleep / Timer
ASPECT [ <> ]/Aspect	TOP MENU D.MENU D.Menu / Top

Original	Substituto

