





















































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	Source		AV
	Sleep		Sleep
	V-Format		Format
	Wide		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Text		Text
	Menu		Menu
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	List		List
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Exit		Exit
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	i		Info





Original	Substituto
 OPT+	 Options
 P+	 Ch +
 P-	 Ch -
 SCHEDULE	 Smart
 Audio	 Dual
 Sub	 Subt
 Tv/Radio	 TV/R

Original	Substituto

